provided that is not rendered inoperable—

- (i) Within the limits of trim and list and list specified in paragraph (a)(4)(iii) of this section;
 - (ii) By OSV motion; or
 - (iii) By power failure.
- (5) Each rigid container for an inflatable liferaft to be launched by a launching appliance must be secured in a way that the container or parts of it are prevented from falling into the water during and after inflation and launching of the contained liferaft.
- (6) Each liferaft must have a painter system providing a connection between the OSV and the liferaft.
- (7) Each liferaft or group of liferafts must be arranged for float-free launching. The arrangement must ensure that the liferaft or liferafts when released and inflated, are not dragged under by the sinking OSV. A hydrostatic release unit used in a float-free arrangement must be approved under approval series 160.162.
- (c) Additional lifefloat stowage requirements. Each lifefloat must be capable of float-free launching and be arranged as follows:
- (1) Lifefloats must be secured to the OSV by— $\,$
- (i) A hydrostatic release unit approved under approval series 160.062 or 160.162 and that is appropriate for the size and number of the lifefloats attached to them: or
- (ii) Lashings that can be easily slipped.
- (2) A painter must be secured to the lifefloat by—
- (i) The attachment fitting provided by the manufacturer; or
- (ii) A wire or line that encircles the body of the lifefloat and will not slip off, and meets the requirements of §133.105(a)(4)(iii).
- (3) If lifefloats are arranged in groups with each group secured by a single painter,—
- (i) The combined weight of each group must not exceed 185 kilograms (407.8 pounds);
- (ii) Each lifefloat must be individually attached to the group's single painter by its own painter which must be long enough to allow floating without contact with any other lifefloat in the group;

- (iii) The strength of the float-free link and the strength of the group's single painter must be appropriate for the combined capacity of the group of lifefloats:
- (iv) The group of lifefloats must not be stowed in more than four tiers. When stowed in tiers, the separate units must be kept apart by spacers; and
- (v) The group of lifefloats must be stowed to prevent shifting with easily detached lashings.

[CGD 84-069, 61 FR 25304, May 20, 1996, as amended at 63 FR 52816, Oct. 1, 1998]

§ 133.135 Rescue boats.

- (a) Each OSV must carry at least one rescue boat. Each rescue boat must be approved under approval series 160.056 and equipped as specified in table 133.175 of this part.
- (b) Offshore supply vessels, as an alternative to the requirement in paragraph (a) of this section, may carry a motor-propelled workboat or a launch if the workboat or launch must meet the embarkation, launching, and recovery arrangement requirements in § 133.160(a), (c), (d), (e), and (f).
- (c) A rescue boat is not required for a vessel operating on the continental shelf of the United States, if—
- (1) The OCMI determines the vessel is arranged to allow a helpless person to be recovered from the water;
- (2) The recovery of the helpless person can be observed from the navigating bridge; and
- (3) The vessel does not regularly engage in operations that restrict its maneuverability.

[CGD 84–069, 61 FR 25304, May 20, 1996, as amended by USCG–2000–7790, 65 FR 58463, Sept. 29, 2000]

§133.140 Stowage of rescue boats.

- (a) Rescue boats must be stowed as follows:
- (1) Each rescue boat must be ready for launching in not more than 5 minutes.
- (2) Each rescue boat must be in a position suitable for launching and recovery.
- (3) Each rescue boat must be stowed in a way that neither the rescue boat nor its stowage arrangements will